



Stylish Seat



Tight Turns



Outdoor



Rising above life's twists and turns.



Blends with Decor



### We are AmeriGlide

AmeriGlide is one of the largest mobility equipment providers in the country. We are committed to providing the best mobility products at the best possible price. AmeriGlide is driven to create mobility and accessiblity products for everyone that help people to go where they want, when they want.

We give people the choice to remain safe and independent in the home they love. Through innovation, we are committed to help people of all ages overcome their limited physical mobility at home and away.

### Reaching New Heights in Your Home

Navigating your staircase doesn't have to be as challenging or intimidating as you think. Your ability to enjoy your life, your family, and your home will be made easier with an AmeriGlide stair lift.

Every year nearly 100,000 people invest in their independence by purchasing a stair lift. You can too.

# Be independent. Feel confident. Be informed about your options.

The best way to get from Point A to Point B isn't always a straight line. A custom built curved stair lift is as unique as its owner. AmeriGlide is among the best in the industry offering fast turnaround times and delivers on quality, form and function. The AmeriGlide Rave HD Curved Stair Lift has a narrow profile, mounting closer to the wall, hugging the stairway with tighter bends and flowing radius curves, allowing for one continuous uninterrupted ride. The ride is ultra smooth, stable and whisper quiet.

With its slimmer sleeker design, ergonomic seating and premium upholstery, you'll get the comfort you expect. Innovative engineering and design from a trusted manufacturer-AmeriGlide, gives you the confidence and freedom to go wherever you want in your home. Whenever you want.



# Did you know?

70% of seniors modifying their homes state safety as the primary reason.\*

\*https://www.aarp.org/content/dam/aarp/research/ surveys\_statistics/general/fixing-to-stay.pdf

### Stylish, and Built to Last

True-Curve System saves space

Stylish, blends with decor

Custom built with durability

Smooth quiet ride

Fast production lead times from factory to your home

#### Peace of Mind Features



Space-saving seat folds to 16" while not in use so others can pass by.



Swivel seating when the chair is stationary for easy entry and dismounts, with lever on both sides of chair.



Integrated sensor plates detect obstruction's and stop the lift.

### **Precision Fabricated & Designed**

AmeriGlide's Rave Curved HD Stair Lift is constructed with highly durable steel rails and gives you the peace of mind you deserve.

Manufactured with precision tube bending techniques and designed and finished by experienced fabricators, the True-Curve Rail and highly engineered motor gear results in an extraordinarily smooth ride. For those concerned with style and house appearance, you'll get the added pleasure of having this stair lift blend with your stair case and home decor.

#### Made in the USA



Outdoor



Customized to Fit Your Stairs



Top and Bottom Landing



Tight Turns

# AmeriGlide's Professional Installation

AmeriGlide Dealers and Installers are throughly trained and certified by AmeriGlide.

AmeriGlide provides them a precision calibrated camera kit for a digitally accurate evaluation to measure your staircase prior to order and manufacture. Our engineering and design of the Rave Curved HD Stair Lift allows for faster and easier installation with simple connect rails, making less fastening into your staircase and less manpower to set the chassis for minimal disruption to you.



All operations are thoroughly checked and adjusted to

you to ensure the most optimal ride. Our installers go over all the operations with you so you may become familiar with your new stair lift. Planning, precision and quality is what sets AmeriGlide apart from others.

### **Custom Configurations to Fit Your Home**

Buying a Rave Curved HD Stair Lift means it's a one of a kind, made just for you. AmeriGlide offers a variety of configurations to fit your stair case and your abilities. Whether that be spiral, multiple turns, or flowing radius curves, we customize your Rave Curved HD Stair Lift to fit your existing stair case, surrounding area and decor. Many customers choose to extend the rail to take them down a hallway, to a bedroom or simply park it out of the way.



Beige rail with long sweeping turn on the wall side of the stairs



Black rail with wide 180° turn on the wall side of stairs



Black rail with 90° turn against the banister side of the stairs



Black rail with tight 180° turn on the inside wall of stairs



Beige rail with wide  $180^{\circ}\,turn$  the landing of the banister side of stairs

### **Rave Curved HD Stair Lift Specifications**

### **Rave Curved HD Models**

#### **Specs**

**Weight Capacity** 

**Drive System** 

**Folded Width** 

**Control Circuit** 

**Standard Colors** 

Max Rail Length

Warranty

**Options** 

Lift Speed

Seat

<b>F</b>	 	 

CSL590 - 90° First Turn



CSL580 - 180° First Turn



CSL570 - Sweep



CSL560 - Spiral

CSL510 - Straight Rail w/ Top or Bottom Overrun CSL511 - Straight Rail w/ Intermediate Landing

Additional operations include 90° turns, 180° turns, parks, intermediate landings, drop nose, and top overruns.

350lbs
Steel Rack and Pinion
20 FPM
19" W x 15" D x 20.5" H
16"
24V DC
Black or Beige
164 Feet
2 Year on Components
Wide seat 21″
Outdoor package (includes cover)
Key switch
Additional call/send
Additional charging station
Custom colors available

# **AmeriGlide Offers Lifts for Home and Away**



Straight Stair Lifts



Vertical Platform Lifts



Wheelchair-Friendly Accessible Vehicles



Incline Platform Lifts