## HIGHLANDER II WITH ENCLOSURE

VERTICAL PLATFORM LIFT ENCLOSURE KIT



Vertical Platform Lifts are required to be enclosed when they have a lifting height of 60" or above for commercial applications and/or when they penetrate a floor. The enclosure kit allows for an integrated solution instead of constructing a hoistway.



## **KEY AVAILABLE FEATURES:**

- Choice of acrylic or steel panels
- Acrylic roof with ventilation system
- Steel frame with SealKor powder coat
- 6' 8" lower door and upper landing gate
- Through-bolt fastening system for enhanced rust protection

## HIGHLANDER II WITH ENCLOSURE PRODUCT SPECIFICATIONS

WEIGHT CAPACITY	750 lb	SPEED	10.4 FPM
DRIVE	<ul> <li>ACME screw</li> <li>90V <sup>2</sup>/₃ HP fully sealed DC gear motor</li> </ul>	POWER	<ul><li>120V AC</li><li>15 AMP circuit breaker</li></ul>
PLATFORM SIZES	<ul> <li>36" x 60" clear platform with 42" guard panel</li> <li>42" x 60" clear platform with 42" guard panel</li> </ul>	WARRANTY	3-year
CERTIFIED	<ul> <li>ETL listed</li> <li>CSA B44.1/ASME A17.5</li> <li>Safety standard ASME A18.1-2017</li> <li>Rated commercial and residential</li> </ul>	FEATURES	<ul> <li>4" x 5" constant pressure paddle control</li> <li>SealKor powder coat with stainless steel hardware for outdoor use</li> </ul>
SAFETY FEATURES	<ul> <li>4-LED indicators in top cap</li> <li>Emergency stop button in platform</li> <li>Overspeed brake</li> <li>Overload protection</li> <li>Interlocks for doors/gates</li> <li>Manual lowering tool</li> </ul>	OPTIONS	<ul> <li>3-stop with 3-button control panel</li> <li>36" or 42" platform gates with EMI</li> <li>interlock</li> <li>Battery backup UPS system</li> <li>Fire-rated doors</li> <li>Grab bar in platform</li> <li>Key lock in platform</li> <li>Safety pan</li> <li>Wired or wireless call/send control</li> </ul>



24MAY2022 | MKT-000192 REV A

